

## The first steps:

If you would like to establish a *Bluetooth* connection for the first time, you must activate the *Bluetooth* function in your mobile telephone and start the search for *Bluetooth* devices. Search for a device with the description „CC 9068“. If several devices have been found, please select and connect the CC 9068 and enter the **PIN number `1234`**. The subsequent functions are described in the operating manual.



## Voice commands which are valid for all menus:

### Cancel

Ends the voice control function.

### Help / What can I say

By saying Help you can hear the commands, which are available in each submenu.

### Back

One step back.

### Head menu

The main menu is open.

## The most important voice commands:

### Head menu

#### Dial Joe Bloggs

Will not be displayed in the head menu. Direct call of a phonebook entry.

If you have saved more than one number for one person, you can dial directly via the category, e.g.

#### „Dial Joe Bloggs home“

It is important to match the announced name exactly with the phone book entry.

#### Dial number

- Digits (0..9)
- Playback
- Delete all
- Delete last
- Dial
- Delete group

Special symbols like +, \* and # can be actuated in the same way as the Pause function (space character) e. g. for mailbox functions.

#### Phone book

- Select entry <digit>
- Playback
- Play list
- Select Joe Bloggs
- Dial
- Dial search
- Get details
  - Dial home
  - Dial mobile
  - Dial office
  - Dial general
  - Dial sim
  - Voicetag
    - Store
    - Number
- Next
- Previous
- Next Page
- Previous Page

#### Redial

Here, you can re-dial the telephone number which was most recently dialled with the hands-free car kit.

#### Call lists

- Dialed calls
- Received calls
- Missed calls

In these menu items the following commands are available to you:

- Select entry <digit>
- Number
- Playback
- Dial
- Next
- Previous
- Next page
- Previous page

#### Music

If a mobile phone is connected with the hands-free car kit in the A2DP mode, you are able to start the playback of music using this command.

## Messages

### Read new message Read new emails

- All messages
- New messages
- All emails
- New emails

Will not be displayed in the head menu. With this voice prompt you can directly reach a new message.

- Bluetooth
- Phones
- Music devices
- A2DP active

- Voice dial
- Magic word
- Advanced help on/off
- Audio feedback on/off
- Speaker adaptation
- Description

- Audio
- Ringtones
- Volume
- Mute delay
- External audio on/off
- Balance
- Installation

- Display
- Sleep mode
- Illumination
- Day/Night mode
- Colour theme
- Calibration
- Rotation

- Device
- Call answering
- Language
- Phone book options
- System
- On-call duty

CC 9068

In these menu items the following commands are available to you:

- Select entry <digit>
- Playback
- Dial
- Read
- Next
- Previous
- Next page
- Previous page

## Settings



### Memo

A voice memo can be saved directly from the main menu or during a telephone call.

### Switch phones




This command is only available as the Multipoint function has been activated. Via this command you are able to swap the priorities of the mobile telephones.

### Activate voice dial

If the Magic Word function is activated, you can start the voice control by this command.



## Handling via touch screen:

All displayed commands can also be operated intuitively via touch screen and are self explaining. Except the commands **Read new message**, **Read new emails** and **Dial Joe Bloggs**. The operation can be carried out via possibly existing arrow keys. With the red symbols   you can cancel an action or go a step back. With the green symbol  you can confirm actions.